

Cleans & Restores Urinal

PeePod™

by AIR SPENCER USA



Step 1

Remove fragrance bar from plastic envelope. Place the fragrance bar over the white tabs that extend out from the back of the PeePod unit. Replace the front grill cover with the label facing forward.



Step 2

Always bend the insertion pin (located on top of PeePod unit) back by 45 degrees. This ensures proper tension on the PeePod unit for insertion into the flush hole where the water for the urinal comes out. (Start from the middle of the urinal and keep moving to the right until the PeePod fits into the flush hole above.)



Step 3

To remove the PeePod, use the blue bag that comes with each unit to cover your hand to protect it from the urinal. Then gently pull the PeePod down and discard the unit into the disposable container, (trash can).



Important note:

If the regular pin on top of the PeePod unit fails to get inserted into the urinal flush hole, then use the suction cup that comes with the PeePod unit. Do this by inserting the stem of the suction cup into the hole located in the back of the PeePod. Clean the surface of the urinal wall with hand soap and paper towel. Scrub gently in a circular motion where the suction cup gets attached to the urinal. The suction cup works better when wet, so flush the urinal before attaching it.



Interesting facts about PeePod:

1. 7 second installation with no tools, tape or screws required.
2. 7 minutes and the fragrance bar fills the entire restroom with organic green fragrance.
3. 7 days and 90% of the urinal smell is eliminated and 50% - 90% of urine stains are washed away.
4. 10 months and the pipes behind the urinal and to the sewer line get restored.

[More information at CleanFreak.com](http://CleanFreak.com)