

2 GALLON SPOTTER Owner's Manual & Parts List

This equipment is intended for commercial use only



TRUSTED CLEAN MODELS

2-55-CS-EC-TC ♦ 2-55-CS-HP-TC

1-888-722-5508

BEFORE OPERATING THIS MACHINE

Read this manual carefully and completely before attempting to operate this unit. This manual has important information for the use and safe operation of the machine. Keep this manual handy at all times. This machine will assure years of satisfactory service if operated and maintained according to recommendations in this manual. If additional information is needed, please contact Cleanfreak at 1-888-722-5508 or write to:

Cleanfreak P.O. Box 569 Wausau, WI 54402

WARNING!

- The machine was designed for use on carpet, floor and upholstery extraction applications as per instructions and recommendations written in this manual. Any deviation from its proper use or purpose and the consequential damage that may occur is the sole responsibility of the end user.
- Disconnect the power cord from the outlet before servicing. Do not leave the machine connected to an electrical outlet when unattended.
- Do not immerse or use this machine in standing water. Such use may cause electric shock.
- This equipment is not designed to handle or use combustible/volatile substances such as gasoline or kerosene, in, on, or near the machine. The use of such materials will cause an extremely hazardous condition.
- When using an extension cord, use only a 3-prong conductor grounding cord- 12 gauge wire or heavier.
- To avoid electric shock, do not expose the machine to rain. Store it indoors only.
- Do not use the machine for dry vacuuming, as it is not equipped with a fine dust filter.
- Use a defoamer at all times to prevent damage to the vacuum motors. If defoamer is not used, or not used sufficiently, foam from your chemical or chemical left in the carpet from a previous cleaning may be ingested into and damage your vacuum motors. Failure to use a defoamer may cause water damage to the vacuum system and void warranty.
- Do not use water in excess of 135°F (57°C) in the solution tank as it may damage the solution system.
- To prevent seal damage and chemical build-up to the pump system, run clean water through the solution lines after each day's use.
- Use only commercially available carpet cleaning solutions and defoamer intended for use with machines of this type.
 Do not use dyes, bleaches, ammonia, or other additives. The use of powdered cleaning solution if not diluted properly may result in damage to the pump. If powdered chemicals are used, premix in a separate container according to directions on the container before placing in the solution tank. Monitor and clean intake filters to prevent clogs.
 Replace damaged filters immediately to prevent damage to pump.
- Do not expose the machine to freezing temperatures, or store inside a room or vehicle where the temperature might drop to freezing temperatures.
- For troubleshooting or technical issues, please contact Cleanfreak.
- Do not use replacement parts other than those specified on the parts list or recommended by a Cleanfreak representative.

FAILURE TO COMPLY WITH ABOVE WARNING INSTRUCTIONS WILL VOID THE WARRANTY

Grounding Instructions

The 120V A/C and the 220V A/C models have been outfitted with the appropriate grounding connector. Make sure the machine is connected to a grounded outlet having the same configuration as the grounded plug. No adaptor should be used with this machine. Any modification to the connector will void the warranty.

PREPARING THE MACHINE

- 1. Unfasten the two latches which hold the recovery tank to the solution tank. Lift the recovery tank off the solution tank.
- 2. Pour clean solution into the solution tank.
- 3. Place the recovery tank back onto the solution tank and fasten the two latches.
- 4. Plug power cord into a grounded power outlet.
- 5. Connect vacuum and solution hoses to the spotter. The connection for the vacuum hose is part of the handle on the recovery tank and has an open end where the vacuum hose slides onto it. The connection for the solution line is located at the bottom center of the front of the solution tank.
- 6. **REMEMBER**: Previously shampooed carpets usually have a heavy build-up of old shampoo residue which can cause the vacuum system to ingest foam and result in damage to the vacuum motor. Remember to add recommended amount of defoamer to the recovery tank every time you fill the solution tank.

OPERATING INSTRUCTIONS – CARPET TOOL

- 1. Turn on the vacuum and solution switches. Slowly pull the tool towards you with solution valve trigger engaged. Do not over wet carpet! Make overlapping passes to prevent streaking.
- 2. When you run out of solution, turn off the switches. Disconnect vacuum hose from recovery tank. Unfasten latches and lift recovery tank off solution tank. Drain recovery tank completely and flush it several times with clean water to remove all dirt and prevent odor build-up.
- 3. When the job is completed, turn the switches off, disconnect the vacuum and solution hoses from the carpet tool and the machine. Drain the recovery tank as in step 2. Tip solution tank upside down over a sink to drain the unused cleaning solution.

CLEANING UPHOLSTERY

Cleaning upholstery with success requires a good knowledge of the type of fabric you will work on. Look for the cleaning instructions label sewn on the underside of the furniture for the recommended method of cleaning. If it calls for dry-cleaning, do not attempt to clean by wet extraction otherwise damage to the fabric could occur. Extraction works perfectly on most synthetic fabrics including synthetic velvets. Always consult your distributor for information on how to find the proper type of chemical and method for the type of fabric you are cleaning.

Before proceeding, test the fabric for colorfastness. Apply a small amount of cleaning solution on the fabric in an inconspicuous spot. Wait 2 to 3 minutes and rub the area with a white terry cloth towel. If no color comes off the towel, the fabric should be safe to clean. If a little color comes off, there is some risk of colors running when you clean. It may be possible to stabilize colors by cleaning with an acidic rinse.

- Prepare the machine in the same manner as for carpet cleaning (see Preparing the Machine) except attach an upholstery
 tool to the vacuum and solution hose instead of a carpet wand. Pour hot water into the solution tank, not exceeding 135°F.
 Add recommended amount of cleaning concentrate into the solution tank. Turn on the vacuum and pump switches.
- 2. Clean with the upholstery tool using as little solution as possible. Make overlapping passes to prevent streaking. Go over the area you just cleaned without depressing the lever (vacuum only) and gauge the amount of moisture extracted through the view window for dryness. On heavily soiled areas like arm rests, pre-treat with a recommended pre-spray solution.

DAILY MAINTENANCE

- 1. Always keep the machine clean inside and out.
- 2. Pour 1 gallon of clean, hot water into the solution tank. Turn on and flush the entire system through the wand nozzles for about a minute to prevent mineral or chemical build-up. A periodic use of a 1:3 white vinegar and water solution helps to break down build up, as well.
- 3. Remove dirt and lint build-up inside the circular filter screen located between the recovery and solution tanks. Lint should be cleaned off so that air flow is not impeded.
- 4. Check the solution tank strainers in the solution tank. If lint has accumulated on the screens, remove and rinse them in clear running water or soak it in a 1:3 white vinegar and water solution. Replace as necessary.
- 5. Empty recovery tank and open recovery lid and run your vacuums for 3-5 minutes after every job to remove any excess moisture from the vacuum motors. This is especially important if you have over filled the machine or did not use enough defoamer.


PERIODIC MAINTENANCE

All Cleanfreak machines are engineered and built to require a minimum amount of maintenance. But like any machine it does require some care to keep it in optimum working condition. Careful attention to these maintenance instructions will give you maximum operating performance and will increase the life expectancy of your machine.

- Solution Lines & Fitting: Flush the machine at least once a month with a solution of 3 parts water with 1 part white vinegar in order to neutralize the alkaline residue left by the cleaning solution.
- Quick Connect Couple: Spray with WD-40 or equivalent lubricant to prevent coupler from sticking.
- Drain Valve: Apply light oil on gate seals. If machine has to be stored for a prolonged period, leave the gate valve open.
- Solution Pump: The same above procedure used on the solution line and fittings applies to the pump.

TROUBLE SHOOTING

PROBLEM	PROBLEM CAUSE		
ELECTRICAL SYSTEM			
No electrical power	Defective power cord		
	2. House or building circuit breaker tripped.		
Switch is turned on. Power	1. Faulty electrical cable.		
is intermittent to all motor(s)	. Defective switches.		
1110101 (5)	3. Loose terminal or discolored terminal connections.		
VACUUM SYSTEM			
No vacuum or low vacuum	1. Vacuum filter between tanks is clogged.		
	2. Vacuum hose is not tight onto recovery tank inlet tube.		
	3. Recovery tank is not firmly clamped down onto solution tank.		
	 Vacuum gasket located between the recovery and solution tanks is worn or damaged. 		
SOLUTION SYSTEM			
Pump motor on, no spray	1. Clogged spray tips.		
through spray tips	2. Clogged solution intake filter screen.		
	3. Plugged female quick disconnect coupler or couplers not fully engaged.		
Uneven or weak spray	1. Clogged or dirty spray tips.		
from tips	2. Accumulated dirt on solution intake filter screen.		
	3. Accumulation of debris inside pump and plumbing.		
	4. Worn nozzles.		



PARTS DIAGRAM

PARTS LIST

1	ITEM#	PART#	DESCRIPTION	QTY.
3 C00314-1 HEX BOLT, ½-20 X 1 2 4 C00233 WASHER, ¾* FLAT 2 5 FO0801-BWG RECOVERY TANK 1 6 D11692 LATCH W/ STRIKER 2 7 C00310-12 SCREW, № 32 X ½* 2 8 E11044 GASKET, 2.25 OD 1 9 E11045 FOAM DISC, 1.5 OD ¾* THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20′, BLACK 1 11 B10719 POWER CORD 16/3, 20′, BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 13 B11199 STRAIN RELIEF 1 14 C00310-38 SCREW, № 32 X ¾* 2 5 SCREW, № 32 X ¾* 2 5 SCREW, 10-32 X ¾* 3 6 6 5 C11529 SCREW, 10-32 X ¾* 3 6 6 6 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, № 3 X ¾* PA BLACK 5 21 C00291 SCREW, № 3 X ¾* PA BLACK 5 22 C00254 ¾* LOCKWASHER 3 23 C00238 WASHER ¾* PA BLACK 5 23 C00238 WASHER ¾* FLAT 3 24 G00520-11 VACUUM MOTOR, 106*, 5.7* REVERSE 1 25 J11154-1 SOLUTION HOSE, ¾* WIRE 3 FT. 26 J00651 SCREW LAWP, 1/4-5/8* 4 4 G00520-11 VACUUM MOTOR, 106*, 5.7* REVERSE 1 27 A00166 90 DEGREE ELBOW, 1/8* PP X ¾* B 1 28 C00252 WASHER ¾* B 1 29 C11701 B01, 3/8 FLAT 3 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8* PP X ¾* B 1 34 C00231 WASHER, ¾* PA X ¾* B A 35 A00121 WASHER, ¾* FLAT 3 36 A00139 ¼* MY X ¼* B BRASS 1 37 C00232 WASHER, ¾* B A 38 A00121 ¼* MP X ¼* B BRASS 1 39 A00104 QUICK DISCHORET, ¾* MALE 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y WASHER, ¾* FLAT 3 39 A00104 QUICK DISCHORET, ¾* MALE 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER, ¾* S Y B BRASS 1 40 K11073 SPACER,	1	F11800-BWG	HANDLE	1
4 C00233 WASHER, %" FLAT 2 5 F00801-BWG RECOVERY TANK 1 6 D11692 LATCH W/ STRIKER 2 7 C00310-12 SCREW, 8-32 X-%" 2 8 E11044 GASKET, 2.25 DD 1 9 E11045 FOAM DISC, 1.5 DD %" THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20', BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 12A B00214-2 COVER, SWITCH, BLACK 1 13 B11199 STRAIN RELIEF 1 14 C00310-38 SCREW, 8-32 X-3/8" 6 15 C11529 SCREW, 10-32 X-3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B022214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 19 F11711 VAC DUCT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, 8-8 X-8 X-9 X-9 RB LACK 5 21 C02291 SCREW, 18-8 X-9 PAN BLACK 5 22 C00254 W" LOCKWASHER 3 23 C00238 WASHER W FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, W WIRE 3 FT. SOLUTION				1
5 F00801-BWG RECOVERY TANK 1 6 D11692 LATCH W/ STRIKER 2 7 C00310-12 SCREW, 8-32 X W" 2 8 E11044 GASKET, 2.25 DD 1 9 E11045 FOAM DISC, 1.5 DD W" THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20', BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 12A B00214-2 COVER, SWITCH BLACK 1 12A B00214-2 COVER, SWITCH 1 13 B11199 STRAIN RELIEF 1 14 C03310-38 SCREW, 8-32 X 3/8" 6 15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 20 C00293 SCREW, 88 X," PAN BLACK 5 21	3	C00314-1	HEX BOLT, ¼-20 X 1	2
5 F00801-BWG RECOVERY TANK 1 6 D11692 LATCH W/ STRIKER 2 7 C00310-12 SCREW, 8-32 X W" 2 8 E11044 GASKET, 2.25 DD 1 9 E11045 FOAM DISC, 1.5 DD W" THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20', BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 12A B00214-2 COVER, SWITCH BLACK 1 12A B00214-2 COVER, SWITCH 1 13 B11199 STRAIN RELIEF 1 14 C03310-38 SCREW, 8-32 X 3/8" 6 15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 20 C00293 SCREW, 88 X," PAN BLACK 5 21	4	C00233	WASHER. ¼" FLAT	2
6 D11692 LATCH W/ STRIKER 2 7 C00310-12 SCREW, 8-32 X W" 2 8 E11044 GASKET, 2.25 OD 1 1 9 E11045 FOAM DISC, 1.5 OD ½" THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20" BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 13 B11199 STRAIN RELIEF 1 14 C00310-38 SCREW, 8-32 X 3/8" 6 15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 19 F11711 VAC DUCT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, 18 X 3" PAN BLACK 5 21 C02291 SCREW, X-20 X 2 3" 3 22 C00254 W-LOCKWASHER 3 23 C00238 WASHER X" FLAT 3 24 G00520-11 VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, X" WIRE 3 27 A00166 90 DEGREE ELBOW, 1/8" PK X" B 1 28 C00252 WASHER 3/8 X 16 X 2 2 INC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11701 BOLT, 3/8-16 X 2, ZINC 2 33 C01323 WASHER X" FLAT 3 34 D11684 INLEST STRAIN S B 2 35 A00152 TEL, YACUUM MOTOR 1 36 A00139 D DEGREE ELBOW, 1/8" FR X " B 1 37 C00232 WASHER X" PLAT 3 38 A00130 90 DEGREE ELBOW, 1/8" FR X " B 1 36 A00139 WASHER X" FLAT 3 37 C00232 WASHER X" FLAT 3 38 A00121 WASHER X BARSS 1 36 A00139 SPACER, WAS BARSS 1 37 C00232 WASHER, X" FLAT 3 38 A00121 WASHER X BARSS 1 40 KINDS SPACER, X 20 X 20 X 20 X 3 SPACE X 3 SP	5		,	
7	h			
8 E11044 GASKET, 2.25 OD 1 9 E11045 FOAM DISC, 1.5 OD %" THICK 1 10 D11043 FIFTER SCREEN 1 11 B10719 POWER CORD 16/3, 20', BLACK 1 12 B1751 ROCKER SWITCH, BLACK 1 12A B00214-2 COVER, SWITCH 1 13 B11199 STRAIN RELEF 1 14 C00310-38 SCREW, 8-32 X 3/8" 6 15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, 8-8 X X "PAN BLACK 5 21 C02291 SCREW, 8-8 X X "PAN BLACK 5 22 C00254 X" LOCKWASHER 3 23 C00293 SCREW, 8-8 X X "PAN BLACK 5 24	 			
9 E11045 FOAM DISC, 1.5 OD X" THICK 1 10 D11043 FILTER SCREEN 1 11 B10719 POWER CORD 16/3, 20', BLACK 1 12 B11751 ROCKER SWITCH, BLACK 1 12A B00214-2 COVER, SWITCH 1 13 B11199 STRAIN RELIEF 1 14 C00310-38 SCREW, 8-32 X 3/8" 6 15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NT 1 19 F11711 VAC DUCT 1 10 F11711 VAC DUCT 1 10 C00293 SCREW, 88 XX" PAN BLACK 5 21 C00293 SCREW, 18 XX" PAN BLACK 5 22 C00254 X" LOCKWASHER 3 23 C00238 WASHER X" FLAT 3 24 G600520-11 VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, X" WIRE 3 FT. SCREW CLAMP, 1/4-5/8" 4 26 J00651 SCREW ELBOW, 1/8 X 3/8 X 13/16 7 27 A00166 90 DEGREE ELBOW, 1/8 X 2X 1/8 B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 29 C11702 HEX NUT, 3/8-16 Z 2 31 C11702 HEX NUT, 3/8-16 Z 2 33 A00130 90 DEGREE ELBOW, 1/8 P N X 8 B 2 34 D11684 NILET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 F P X 1/8 F P 1 36 A00139 XMP X BARB, BRASS 1 37 C00232 WASHER, 3/8 X 13/16 7 39 A00104 QUICK DISCONNECT, X" MALE 1 30 MASHER, X" FLAT 3 31 F10521 GASKET, VACUUM MOTOR 1 31 F10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 P N X 1/8 F P 1 1 36 A00139 XMP X 1/8 F P X 1/8 F P 1 1 37 C00232 WASHER, 3/8 X 13/16 7 38 A00152 TEE, 1/8 MP X 1/8 F P X 1/8 F P 1 39 A00104 QUICK DISCONNECT, X" MALE 1 40 K11073 SPACER, X-2 OX N D X 1 X LONG 3 41 F11803-STCB MASHER, 3/6 N D D N A SHER, 3/8 T D D D D D D D D D D D D D D D D D D	h			
10			,	
11	h		·	
12				
12A B00214-2 COVER, SWITCH 1 1 1 1 1 1 1 1 1	h			
13	-		,	
14				
15 C11529 SCREW, 10-32 X 3/8" 2 16 D11699 SWITCH PLATE 1 17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, #8 X %" PAN BLACK 5 21 C02291 SCREW, #8 COV 2 X" 3 22 C00254 %" LOCKWASHER 3 23 C00238 WASHER %" FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, X" WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X %" B 1 28 C00252 WASHER, 3% X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X % B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 WASHER, 3/" FLAT 3 37 C00232 WASHER, %" FLAT 3 38 A01100 SPACER, X-20 X 9 DE A SERSE	· -			
16	-			
17 E11722 GASKET, VENT PLATE 1 18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, #8 X'S" PAN BLACK 5 21 C00291 SCREW, #2 V'S" 3 22 C00254 W"LOCKWASHER 3 23 C00238 WASHER W"FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, W"WIRE 3 FT. 26 J00651 SCREW LAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X W"B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X W B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 WASHER, 3/8 Y 18 FP X 1/8 FP 1 37 C00232 WASHER, 3/8 FP X 1/8 FP 1 38 A00121 WASHER, W"F FLAT 3 39 A00104 QUICK DISCONNECT, W" MALE 1 40 K11073 SPACER, W-20 XY OD X1 % LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, 490 OD 4 42 C90007-1 SCREW, 10-32 XI PHILT REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLOW MP X W B 2 50 C11724 3/8-16, WELD NUT 2 50 C11724 3/8-16, WELD NUT	h			
18 B02214 STRAIN RELIEF NUT 1 19 F11711 VAC DUCT 1 20 C00293 SCREW, #8 X %" PAN BLACK 5 21 C02291 SCREW, #8 X %" PAN BLACK 5 22 C00254 %" LOCKWASHER 3 23 C00238 WASHER %" FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, %" WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X %" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 B0LT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X % B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 % MS PX 1/8 FP X 1/8 FP 1 36 A00139 % MS PX 1/8 FP X 1/8 FP 1 37 C00232 WASHER, %" FLAT 3 38 A00121 % MP X % BARB, BRASS 1 39 A00104 QUICK DISCONNECT, %" MALE 1 40 K11073 SPACER, %-20 X % OD X 1 % LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, 490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1/4" 2 45 J00618-1 VACUUM HOSE, 1 %", WIRE 8 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 50 C11724 3/8-16, WELD NUT 2				
19 F11711 VAC DUCT 1 20 C00293 SCREW, #8 X %" PAN BLACK 5 21 C02291 SCREW, #8 X %" PAN BLACK 5 22 C00254	-		,	
SCREW, #8 X %" PAN BLACK 5	-			
21 C02291 SCREW, %-20 X 2 ½" 3 22 C00254 ½" LOCKWASHER 3 23 C00238 WASHER ½" FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, ½" WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X½" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ¼ MP X ¼ BARB, BRASS 1 37 C00232 WASHER, ¾"FLAT 3 </td <td></td> <td></td> <td></td> <td></td>				
22 C00254 %" LOCKWASHER 3 23 C00238 WASHER %" FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, %" WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X %" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X % B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 % MP X % BARB, BRASS 1 37 C00232 WASHER, 3/6" FLAT 3 38 A00121 % MP X % BARB, BRASS 1	-		,	
23 C00238 WASHER %" FLAT 3 24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, %" WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X %" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X % B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 % MP X % BARB, BRASS 1 37 C00232 WASHER, %" FLAT 3 38 A00121 % MP X % FP BRASS 1 39 A00104 QUICK DISCONNECT, %" MALE			·	
24 G00520-1L VACUUM MOTOR, 106", 5.7" REVERSE 1 25 J11154-1 SOLUTION HOSE, W WIRE 3 FT. 26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X W" B 1 28 C00252 WASHER, 3/8 x 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP RASS 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490	-			
SOLUTION HOSE, %" WIRE 3 FT.	h			
26 J00651 SCREW CLAMP, 1/4-5/8" 4 27 A00166 90 DEGREE ELBOW, 1/8" FP X ½" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE <td>-</td> <td></td> <td></td> <td></td>	-			
27 A00166 90 DEGREE ELBOW, 1/8" FP X %" B 1 28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ¼ MP X ¼ BARB, BRASS 1 37 C00232 WASHER, ¾" FLAT 3 38 A00121 ¼ MP X ¼ FP BRASS 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, 490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½"				
28 C00252 WASHER, 3/8 X 13/16 7 29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ¾" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ¾" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, 490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" <t< td=""><td>h</td><td></td><td></td><td></td></t<>	h			
29 C11701 BOLT, 3/8-16 X 2, ZINC 2 30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORC				
30 G11688 WHEEL, 6" 2 31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ¼ MP X ¼ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ¼ MP X ¼ FP BRASS 1 39 A00104 QUICK DISCONNEOT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1½" 2 45 J00618-1 VACUUM HOSE, 1½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 50 C11724 3/8-16, WELD NUT 2	h			
31 E10521 GASKET, VACUUM MOTOR 1 32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ¼ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ¼ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 50 C11724 3/8-16, WELD NUT 2			, , , , ,	
32 C11702 HEX NUT, 3/8 16 2 33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACK			,	
33 A00130 90 DEGREE ELBOW, 1/8 MP X ½ B 2 34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ¼ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT	-			
34 D11684 INLET FILTER 2 35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD			· ·	
35 A00152 TEE, 1/8 MP X 1/8 FP X 1/8 FP 1 36 A00139 ½ MP X ½ BARB, BRASS 1 37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT 2				
36 A00139	h			
37 C00232 WASHER, ½" FLAT 3 38 A00121 ½ MP X ½ FP BRASS 1 39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ½ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT 2	35		, , , , , , , , , , , , , , , , , , , ,	1
38 A00121 ¼ MP X ¼ FP BRASS 1 39 A00104 QUICK DISCONNECT, ¼" MALE 1 40 K11073 SPACER, ¾-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2			,	
39 A00104 QUICK DISCONNECT, ½" MALE 1 40 K11073 SPACER, ½-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1½" 2 45 J00618-1 VACUUM HOSE, 1½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT 2	-			
40 K11073 SPACER, ¼-20 X ½ OD X 1 ¾ LONG 3 41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT 2				
41 C03251 WASHER, 3/6" ID, BACKUP, .490 OD 4 42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	-			
42 C90007-1 SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS 2 43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	40		,	3
43 F11803-STCB MOTOR BASE 1 44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	41	C03251		4
44 J00656 HOSE CLAMP, 1 ½" 2 45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	42	C90007-1	SCREW, 10-32 X 1" PHIL TRUSS HEAD, SS	2
45 J00618-1 VACUUM HOSE, 1 ½", WIRE REINFORCED 10" 46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	43	F11803-STCB	MOTOR BASE	1
46 G11689 PUMP, OSCILLATING 1 47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ½ B 2 50 C11724 3/8-16, WELD NUT 2	44	J00656	·	
47 C00278 NYLON LOCKNUT, 10-32 1 48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	45	J00618-1	VACUUM HOSE, 1 ½", WIRE REINFORCED	10"
48 E11691 PUMP BRACKET 2 49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	46	G11689	PUMP, OSCILLATING	1
49 A00134 90 DEGREE ELBOW, 1/8 MP X ¼ B 2 50 C11724 3/8-16, WELD NUT 2	47	C00278	NYLON LOCKNUT, 10-32	1
50 C11724 3/8-16, WELD NUT 2	48	E11691	PUMP BRACKET	2
	49	A00134	90 DEGREE ELBOW, 1/8 MP X ¼ B	2
51 F11802-BLANK-STCB SOLUTION TANK 1	50	C11724	3/8-16, WELD NUT	2
	51	F11802-BLANK-STCB	SOLUTION TANK	1

NOT SHOWN

52	F11723	CLEAN OUT PORT	1
53	C02237	SCREW, PHILLIPS (CLEAN OUT PORT)	6

NOTES



REVISED 06-21-2013